

Electron-hadron separation in electromagnetic calorimeters: a comparison

Iván Esteban Muñoz

University of the Basque Country

August 21, 2014

Purpose

- Identification: scattered electron vs negatively charged hadrons in DIS
- Tracker
- Electromagnetic calorimeter

$$\Downarrow$$
$$E/p$$

Purpose




Figure 1 : Lead glass calorimeter, 15 GeV x 250 GeV

- PEPSI e-p polarised in parallel $15\text{GeV} \times 250\text{GeV}$
- Calorimeter smearing models for electromagnetic particles:
 - Lead-tungstate:
$$\begin{cases} \Delta E/E = 0.69\% + 1.78\%/\sqrt{E} & (\eta < -2) \\ \text{Tungsten powder performance} & (\eta > -2) \end{cases}$$
 - Lead glass:
$$\begin{cases} \Delta E/E = 0.76\% + 5.95\%/\sqrt{E} & (\eta < -1) \\ \text{Tungsten powder performance} & (\eta > -1) \end{cases}$$
 - Tungsten powder: $\Delta E/E = 1.4\% + 9.7\%/\sqrt{E}$
- Calorimeter smearing model for hadrons:

$$\mu/E = 40\% \quad \sigma/E = 10\%$$

Momentum resolution

$ \eta $	$\Delta p/p$
[0.00, 0.25]	$0.69\%/p + 0.14\% + 0.041\%p$
[0.25, 0.75]	$0.49\%/p + 0.21\% + 0.030\%p$
[0.75, 1.25]	$-0.013\%/p + 0.40\% + 0.014\%p$
[1.25, 1.75]	$0.38\%/p + 0.68\% + 0.016\%p$
[1.75, 2.25]	$0.22\%/p + 0.61\% + 0.020\%p$
[2.25, 2.75]	$0.82\%/p + 0.79\% + 0.019\%p$
[2.75, 3.00]	$2.0\%/p + 1.2\% + 0.061\%p$

- How are electrons and negatively charged hadrons distributed in momentum space?
- Which rapidities are interesting?

Kynematics

Momentum distribution




Figure 2 : Electron and negative hadron distribution in momentum space

Kynematics

Rapidity vs Q^2




Figure 3 : Q^2 vs η of the scattered electron

Results

General results

- Purity $\equiv 1 - \frac{\#had}{\#scat. e^-}$ ($\pm 3\sigma$)
- σ for scattered electron E/p
- Momentum dependance
- Rapidity bins

Results

General results: purity




Figure 4 : Purity comparison ($\pm 3\sigma$)

Results

General results: width for the electron signal




Figure 5 : σ comparison for the electron signal

Results

General results

- Graphical visualization
- Overlap
- Momentum and rapidity bins

Results

General results: graphical visualization




Figure 6 : Overlap for different p and η bins (tungsten powder)

Results

Particular results

- Alternative to $\pm 3\sigma$, fixed left cut \Rightarrow error
- Efficiency $\equiv 1 - \frac{\#scat. e^-}{total\ scat. e^-}$

Results

Particular results: 0.7 cut




Figure 7 : Purity for a cut at $E/p = 0.7$




Figure 8 : Efficiency for a cut at $E/p = 0.7$

Results

Particular results: 0.8 cut




Figure 9 : Purity for a cut at $E/p = 0.8$




Figure 10 : Efficiency for a cut at $E/p = 0.8$

Results

Particular results: 0.9 cut




Figure 11 : Purity for a cut at $E/p = 0.9$




Figure 12 : Efficiency for a cut at $E/p = 0.9$

Results

Particular results

- Original separation in momentum space between electrons and hadrons: high purities by binning
- Still some momentum migration
- Graphical visualization of both purities
- Momentum *relative migration* because of smearing: $p_{rec} - p_{sim}^e$

Results

Particular results: momentum migration




Figure 13 : Momentum migration for the tungsten powder calorimeter

Results

Particular results: momentum migration projection




Figure 14 : Momentum migration projection for the tungsten powder calorimeter

Conclusions

- High purity, regardless of the cal
- Good resolution in momentum space
- May achieve high purities at low momenta with a restrictive cut

Acknowledgements

Elke-Caroline Aschenauer

Alexander Kiselev

Thomas Burton

Backup

Lead Tungstate E/p




Figure 15 : Lead tungstate calorimeter, 15GeVx250GeV

Backup

Tungsten powder E/p




Figure 16 : Tungsten powder calorimeter, 15 GeV \times 250 GeV

Backup

Lead tungstate overlap




Figure 17 : Overlap for different p and η bins (lead tungstate)

Backup

Lead glass overlap




Figure 18 : Overlap for different p and η bins (lead glass)

Backup

Lead tungstate momentum migration




Figure 19 : Momentum migration for the lead tungstate calorimeter

Backup

Lead glass momentum migration




Figure 20 : Momentum migration for the lead glass calorimeter

Backup

Lead tungstate momentum migration projection




Figure 21 : Momentum migration projection for the lead tungstate calorimeter

Backup

Lead glass momentum migration projection




Figure 22 : Momentum migration projection for the lead glass calorimeter