
Tests of the JLab FADC250

(250 MHz, 12 bit)


Tests:

- Internal noise during VME readout
- AGS pCarbon
 - baseline (depending on detector and intensity)
 - carbon and prompt signals
- Jet
- RHIC pCarbon

Noise in the FADC (No Readout during data taking)



Noise in the FADC (Readout during data taking)



AGS Polarimeter

Trigger: BunchZero (not synchronized with clocks)

Inputs: 0. BunchZero

1. BunchZero + 2 ns


2. WCM (software trigger)

3. Inner Detector Strip

4. Outer Detector Strip

Data: 256 samples for every input


Flattop selection (0.7 sec)





Pairs of strips (0,84), (12,72), (24,60), (36,48) were tested with and without target at Beam intensity 1.5


Strips 0,84 were also tested with and without target at Beam Intensity 1.3, 0.7, 0.35


AGS: Wall Current Monitor Signal





























AGS: Chan. 84 (Ham, Slow, Outer) Intensity 1.7



Preliminary Summary for AGS Polarimeter

- Clear picture of "induced pulses" / noises was obtained
- 4.5 MHz oscillation signal does not depend on beam intensity. Amplitude is at level of sensitivity of our WFDs.
- Induced pulse is actually a long lasting (~200-250 ns) beam intensity dependent oscillation signal. The main source of "corrupted" banana at AGS.
- A big scattered protons signal appears when target is entered to beam.
- Data analysis is not completed yet.





<u>H-Jet</u>

Trigger: BunchZero coincidence with Signal 1 or 2


(not synchronized with clocks)


Inputs: 0. BunchZero

1. Signal 1 (not amplified in shaper)

2. Signal 2 (not amplified in shaper)

Data: 256 samples for every input






To be analyzed

RHIC p-Carbon

Yellow? Polarimeter (measurements in background)

Trigger: one of 2 strip signals above threshold

Input: one channel from every detector



To be analyzed

Summary

- A FADC250 board was tested with VME(software) and external triggers
- Not all features were studied.
- Low internal noise, $\sigma \approx 1.4$ cnts. (smaller then white noise in polarimeter $\sigma \sim 5-10$ cnts). Internal noise is independent on VME bus activity.
- Readout rate was about 15 Mbyte/sec during test measurements. We need
 80 Mbyte/sec for nonstop measurements of the polarization at RHIC pCarbon.
- Real data from AGS and RHIC pCarbons and H-Jet were recorded.
- Data analysis is in progress.
- This data may (must) be used for the developing of firmware algorithms.
- **Preliminary:** FADC250 may be used in AGS/RHIC polarimeters upgrades